LG Vu CU920 Battery Replacement

Replacing a battery in a LG Vu

Written By: Alan Reeve



INTRODUCTION

Use this guide to install a new battery in your LG Vu.


Step 1 — Battery





- Remove the back cover by firmly pressing against the indent on the back panel. Slide the cover downward and off the phone.

Step 2




- Remove the battery by placing your fingernail or an opening tool at the bottom edge of the battery and lift it out.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 09:26:35 PM.